



# R Series Firmware Update Guide

This guide explains how to update the R series and Tio1608-D firmware by using the R Remote (V4.1.0 or later).


## Precautions

- Note that the device may be damaged if you fail to follow these instructions properly, or turn off the device or disconnect the cable while the update is in progress.
- Yamaha Corporation owns exclusive copyrights for the firmware, its update program, and the update guide.
- It is prohibited to duplicate or modify the firmware, software or guides, in part or in their entirety, without permission from the copyright owner.
- The screen shots in this guide are for use with this update procedure only and may be different from the actual screen shots.
- Windows is a registered trademark of Microsoft ® Corporation in the United States and other countries.
- Mac and Macintosh are trademarks of Apple Inc., registered in the U.S. and other countries.
- The company names and product names in this document are the trademarks or registered trademarks of their respective companies.

## Update operation

This section describes how to update the firmware.

1. Start R Remote. Choose “Tool” → “Firmware Update” from the menu of R Remote.  
Firmware Updater starts up.



2. (In the case of RMio64-D) Quit the NUAGE Workgroup Manager if it is running.
3. Press the “Select” button and select the firmware “xxxx\_v\*\_\*\*\_rrmt.bin” to be updated  
Devices that can be updated appear in the device information area.

**NOTE** xxxx represents the product name and \*\_\*\* represents the firmware version number.  
(E.g. rio3224-d\_v4\_10\_rrmt.bin)

**NOTE** When you select an old firmware which is not supported by R Remote, "invalid file" appears and the update cannot be started.

**NOTE** If the firmware of the device is an older version than the firmware file, the checkbox for its device will be automatically checked.  
If the firmware of the device is a newer version or a same version, you will need to check manually to the checkbox of the firmware to update.

4. Press the "Update" button to start the update.
5. When the update is complete, a popup window appears. Press the "OK" button.
6. Turn the updated device off and then on again.

For details on updating the unit, refer to the "R Remote V4.1 User's Guide" available on the website.  
<http://www.yamahaproaudio.com/>